

Silky Sensuede

1. **95% Polyester - 5% Polyurethane**
2. **51" Wide**
3. **Piece Length: 33 Yards**
4. **Weight: 8.5 Ounces Per Linear Yard**
5. **Cleanability: "SW" - No Scotchgard® Needed**
6. **Abrasion Resistance (Wyzenbeek)**
 - Exceeds 50,000 Double Rubs on the Wyzenbeek Machine

HANDLING AND CARE

Washable, Wrinkle Resistant, And Colorfast...
Will not Shrink, Pill; Crock Or Fade...

SENSUEDE is easy care. Unlike natural skins, *SENSUEDE* is resistant to stains and if stains occur, they can be easily removed as follows:

To remove light stains, brush with a suede brush. For deeper stains, brush with an eraser or fine sandpaper. For sticky stains such as honey and sweets, use spoon or knife to remove. Avoid rubbing stains into the material. General stains can be removed with a dampened soft cloth.

If the stains persist, use the following cleaning method:

LIQUID STAIN (Coffee, Tea, Juice, Milk, Coke, Beer, Wine, Sauce, Ketchup, Ink, etc.): Blot the spot to remove excess liquid, remove the stains with a cloth soaked in warm, sudsy water. Place a dry cloth on the reverse side to absorb excess water. Repeat until stain is removed and no soap remains.

OIL BASED STAIN (Butter, Mayonnaise, Salad Oil, Lipstick, Cosmetic, Shoe Polish, Ball Point Pen, Marker, Machine Oil, etc.): Try the same thing as above described. If the stain remains, gently rub the spot with a cloth dampened with benzine, alcohol, or a dry cleaning agent.

OTHER STAINS (Paints, Varnish, etc.): Use the remover designed for the staining agent (for example, turpentine for paint and varnish). As chemicals can harm or discolor the material, first test the remover on a corner of the fabric.

Once the stain is removed, blot again with dry cloth to remove any excess water and let the cloth air dry.

SENSUEDE can be machine washed in cool water with a mild detergent. **DO NOT BLEACH. DO NOT DRY IN A HIGH-TEMPERATURE DRYER.**

When *SENSUEDE* is dry, brush the fabric with a suede brush to restore the natural sheen and luster of the cloth. Iron on reverse side at cool setting. *SENSUEDE* can also be professionally dry cleaned.